


MODEL TD-2

**ON-LINE LTC TEMPERATURE DIFFERENTIAL MONITOR
(FOR TRANSFORMERS WITH DUAL TANK LTCs)
Monitoring & LTC Failure Avoidance Alarm**

BCI Bulletin BCI-TD2 Revision 6/28/2009


CONTENTS		Page
I.	Description of Operation	2
	Main menu & keypad	5
	Configuration menu	6
	Configuration/Calibration displays	7
	Communications	9
	Serial Cable Interface Pin Out	10
	Analog scaling values	10
	Configuration jumpers	12
II.	Installation	13
	Front view TD-2	14
	Mounting	14
	Calibration [also refer to page 7]	15
	Specifications	16



I. Description of Operation

The model TD-2 is a solid state device that monitors differential temperature (ΔT) between the transformer main tank and two load tap changer (LTC & Diverter) compartments. The unit is SCADA ready and provides alarming for dual differential temperatures. The TD-2 is designed for easy installation on transformers and requires no internal tank connections.

Heating in the LTC compartment is a key indicator of potential failure. By monitoring the temperatures in both the main transformer tank and the LTC compartments, early detection and alarming can provide a real edge in failure avoidance. While no system can prevent every failure, the TD-2 is a cost effective tool in monitoring and alarming to provide both, a maintenance alert for slowly increasing ΔT or imminent failure warning for high ΔT . Failures originating in LTC mechanisms are common in the industry. TD-2 provides the edge for failure risk management, while providing a maintenance indicator measurable at the same time.



TD-2 With Typical SCADA Trending Data

The temperatures are monitored by using three 75LB pull magnetic surface mount platinum 100 Ohm RTD each, on the exteriors of the LTC & Diverter compartments and main transformer tank at an upper location in oil space. The unit includes 30 year UV treated SJT jacketed connecting cables for the three RTD magnetic sensor units.

The TD-2 has three SCADA analog output channels and three independently adjustable dry contact relays for local alarming functions. Factory settings are -1 deg C for ordinary and -5 deg C for urgent alarms. A high temperature alarm is included. Factory default high temperature alarm is 80 deg C. Alarm setpoints are easily changed on or off site.

The display is shown at all times, except during user entry and menu action. The default top line of the display is differential temperature #1(ΔT), main tank temperature, differential temperature #2, Bottom line includes valley (LTC) temperature #1, main tank peak temperature and valley (LTC) temperature #2..

LTC Failure and LTC Temperature

Main Dial Switch

- | | |
|------------------------|----------------------|
| 1. Arcing tip fracture | Temperature Increase |
| 2. Oxidation | Temperature Increase |
| 3. Overload | Temperature Increase |
| 4. Misalignment | Temperature Increase |
| 5. Poor maintenance | Temperature Increase |

Reversing Switch Failure

- | | |
|----------------------------|----------------------|
| 1. Inactivity in operating | Temperature Increase |
| 2. High contact resistance | Temperature Increase |
| 3. Overheating | Temperature Increase |
| 4. Coking - Carbonizing | Temperature Increase |

Load Transfer Switch Failure

- | | |
|--|----------------------|
| 1. Contact erosion from normal load | Temperature Increase |
| 2. Mechanical failure from poor timing | Temperature Increase |
| 3. Improper contact alignment | Temperature Increase |
| 4. Improper contact pressure | Temperature Increase |
| 5. Weak drive spring assembly | Temperature Increase |

Main Diverter Tank

- | | |
|--------------------------------------|----------------------|
| 1. Carbon build up | Temperature Increase |
| 2. Dielectric strength deterioration | Temperature Increase |

Drive mechanism


- | | |
|--------------------------------|----------------------|
| 1. Faulty mechanism | Temperature Increase |
| 2. Inter tap interlock failure | Temperature Increase |

Loading

- | | |
|----------------|----------------------|
| 1. Overloading | Temperature Increase |
|----------------|----------------------|

The above list was compiled from actual historical records of various LTC failures and causes. Temperature is the most universal indicator for this list. This includes situations where fault gas is not generated but heating takes place due to overloading, or lack of adequate contact pressure. Contact wear occurs as the load tap changer operates to maintain a constant voltage with varying load. This erosion is a normal operating characteristic, but the rate can be accelerated by improper design, faulty installation, misalignment, and high loads. The TD-2 can detect and alarm, even when the heating condition only occurs during peak loading. In this way the ΔT (differential temperature) alarms can be set to flag the need for routine LTC maintenance or alarm for immediate action (failure avoidance). The TD-2 is the answer to both needs.

Coking usually occurs at the end of the normal contact life cycle. Contact wear is proportional to the square of the current through the contacts, therefore heavily loaded LTCs may create a thermal runaway condition in which contact resistance increases rapidly, causing more coking and more heating. Arcing is normal for reactance and resistive type LTCs. This produces carbon which can be deposited on the tap changer contacts. This layer of carbon can increase the resistance of the contacts and cause heating and coking. Thus the cycle is again a thermal indicator and self destructive. (*Normal tap changer contact resistance is commonly maintained at less than 80 microohms.*)



Common Causes of Thermal Runaway Conditions

Cause	Symptom	TDM Alarms
Arcing time increase	Temperature increase	YES
Oil carbonizes quicker	Temperature Increase	YES
Increased contact wear	Temperature Increase	YES
Increased arcing time	Temperature Increase	YES
Increased contact oxidizing	Temperature Increase	YES
oil sludge's (Dirty Oil)	Temperature Increase	YES
Loading (excessive)	Temperature Increase	YES
Faulty installation, etc.	Temperature Increase	YES
Misalignment	Temperature Increase	YES

SAFETY!

The TD-2 is a product that can alert utility companies to all of the above abnormal conditions in Load Tap Changers. Extra precautions should then be taken when manually operating LTCs which show symptoms of internal abnormalities.

**Employee Caution & TD-2 working together to reduce risk,
Increase safety margin, & keep employees SAFE!**

Front Panel & Display

The TD-2 features a new, user friendly interface. At the heart of this interface is a 2 line by 16 character alphanumeric display and a five key keypad.

The TD-2 unit features a standard display of temperature data. This standard display is shown at all times except when a user has entered one of the two menus to setup the control of the unit. If the user leaves the unit in one of these menus, it will timeout and return to the standard display.

Standard Temperature Display

DIFF 1	MAIN	DIFF 2
-2.8	73.1	+2.6
-3.2	77.9	-3.0
VALLEY	PEAK	VALLEY

The display shows the current differential temperature of two LTC tanks, the main tank temperature and the two "valley" difference temperatures seen since the last reset. Pressing both the " UP " & " DOWN " resets this value to the current difference temperature.

KEYPAD KEYS

MENU When pressed and released, the unit starts the main menu sequence of displays to allow the user to setup the normal operating parameters. When held for three seconds, the unit enters the configuration menu. This secondary menu allows the user to setup the units configuration and calibration of the unit.

NEXT When the unit is displaying the standard display, no action is taken. When in the main or secondary menu, pressing this key will advance to the next item in the menu's sequence.

PREV When the unit is displaying the standard display, no action is taken. When in the main or secondary menu, pressing this key will return to the previous item in the menu's sequence.

∇ When the unit is displaying the standard display, no action is taken. When in the main or secondary menu, pressing this key will advance the current parameter to the next possible value.


Δ When the unit is displaying the standard display, no action is taken. When in the main or secondary menu, pressing this key will change the current parameter to the previous possible value.

∇ Δ Simultaneously pressing both the ∇ Δ and will reset the valley temperature to current value.

The lists below detail the sequence for each menu item. The COMM column indicates which values may be read and /or written through the communication link.


MAIN MENU ITEMS

COMM. DISPLAY	ACTION	DESCRIPTION	COMM
DIFF TEMP WARN <value>	Numerical entry Note ΔT will be negative value when LTC temperature is greater than that of main tank ($\Delta T = \text{main tank oil temp} - \text{LTC compartment oil temp}$)	Differential temperature warning value Default -1 degrees C, range -40C to +180C	no
DIFF TEMP ALARM <value>	Numerical entry Note ΔT will be negative value when LTC temperature is greater than that of main tank ($\Delta T = \text{main tank oil temp} - \text{LTC compartment oil temp}$)	Differential temperature urgent value Default -5 C degrees C, range -40C to +180C	no
HIGH TEMP ALARM <value>	Numerical entry	High temperature alarm value Either LTC or main tank temperature that exceeds this high temp alarm trigger (setpoint) will initiate alarm. Default -5 C degrees C, range -40C to +180C	yes
HYSTERESIS <value>	Numerical entry	Control hysteresis value establishes a "deadband" before reset Default set at 0.1 C Range 0.1 to 100.0 C	yes
ALARM DELAY <value>	Numerical entry	This value establishes a time delay before alarm initiation Default = 10 seconds Range 1.0 to 1000 seconds	yes





CONFIGURATION & CALIBRATION MENU ITEMS

COMM. DISPLAY	ACTION	DESCRIPTION	COM M
COMM MODE <mode>	Down/Up to select	Communications mode Modes: RS232, RS485, RS485 Multi-point	no
COMM RATE <rate>	Down/Up to select	Communication baud rate Possible rates: 1200, 2400, 4800, 9600	no
COMM FORMAT < format >	Down/Up to select <i># bits- parity check- stop bit</i>	Communication data format Possible formats: 8-N-1, 7-N-1, 7-E-1	no
COMM ADDRESS < address >	Value entry for RS485 <i>Allows 1 modem to address multiple unit addresses</i>	Communication address (RS485 Multi only) Possible values: 0-255	no
COMM PERIOD	Value entry <i>0.0 selects no output</i>	Communication output period Range: 0.0 to 3000.0 minutes	yes
COOLDOWN LOCKOUT	Down/Up to select "OFF" or ON"	If selected to "ON" mode, alarming & valley update is disabled while LTC temperature is decreasing	yes
ANALOG 1 OUT <mode>	Down/Up to select	Analog output 1 mode (main tank) Possible modes- 0 -1ma, 4-20ma, 0-5v	no
ANALOG 2 OUT <mode>	Down/Up to select	Analog output 2 mode (LTC compartment) Possible modes- 0 -1ma, 4-20ma, 0-5v	no
ANALOG 3 OUT <mode>	Down/Up to select	Analog output 3 mode (ΔT main tank minus LTC) Possible modes- 0 -1ma, 4-20ma, 0-5v	no
RTD 1 OFFSET	Value entry <i>Determined by calibration to known temperature</i>	RTD 1 offset value in tenths of a degree Range: -20.0 to +20.0°C	read
RTD 2 OFFSET	Value entry <i>Determined by calibration to known temperature</i>	RTD 2 offset value in tenths of a degree Range: -20.0 to +20.0°C	read
RTD 3 OFFSET	Value entry <i>Determined by calibration to known temperature</i>	RTD 3 offset value in tenths of a degree Range: -20.0 to +20.0°C	read



TD-2 DISPLAY SCREENS





ANALOG SCALING VALUES

	0 to 1 mA	4 to 20 mA	0 to 5 VDC
Temperature 0°C	0.200 mA	10.00 mA	1.00 VDC
Slope per °C	0.004 mA	0.050 mA	0.020 VDC
Minimum Scale	0 mA = -50°C	4 mA = -120°C	0 VDC = -50°C
Maximum Scale	1 mA = +200°C	20 mA = +200°C	5 VDC = +200°C
Differential Temp 0°C	0.500 mA	12.00 mA	2.50 VDC
Slope per °C	0.004 mA	0.050 mA	0.020 VDC
Minimum Scale	0 mA = -125 °C	4 mA = -160°C	0 VDC = -125 °C
Maximum Scale	1 mA = +125 °C	20 mA = +160 °C	5 VDC = +125 °C

TD-2 – IBM INTERFACE CABLE (PC SERIAL CABLE)

SIGNAL	TD-2	9 PIN SERIAL CABLE
RS232		
DATA FROM PC	PIN 3	PIN 3
DATA TO PC	PIN 4	PIN 2
GROUND	PIN 2	PIN 5
RS-485		
DATA +	PIN 4	
DATA -	PIN 5	


RS232 TERMINAL SETTINGS: Emulation – ANSI, Data Bits – 8, Parity – None, Stop Bits – 1, Flow Control – None, Keyboard Caps – On. (Remove JMP1)
HyperTerminal can be used. (supplied with Windows 98®)

EXPLANATION OF HYSTERESIS

The HYSTERESIS setting is a deadband adjustment for toggling an event or alarm. It is there to increase stability and prevent fast on-off operations of alarms and events.

Example 1: HYSTERESIS = 1.0 deg C and High Temp Alarm is set for 80 Deg C.)
Alarm is activated at 80 Deg. C (After ALARM TIME DELAY)
Alarm will not reset until temperature is 79 Deg. C.

Example 2: HYSTERESIS = 0.1 deg C (default) and differential alarm is set for -5 Deg C.)
Alarm is activated at -5 Deg. C (After ALARM TIME DELAY)
Alarm will not reset until temperature is -4.9 Deg. C.



COMMUNICATIONS STRING FORMAT:

Syntax:

- [.] Optional items
- <..> Value field
- ? Value query
- * Preceding item may be repeated
- <cr> Carriage return
- <lf> Line feed
- <chksum> Checksum, sent only if received with command.
Sum of all ASCII characters up to and including '='.

COMMANDS:

[<adr>:] <nem> (?<value>) [,<nem> (?<value>)]* [=<chksum>] (<cr>|<lf>)

- | | | | |
- | | | | | _ Ending
- | | | | | _ Optional checksum
- | | | | | _ Mnemonics may be repeated
- | | | | | _ Query (?) or value
- | | | | | _ Mnemonic command - see tables below
- | | | | | _ Communication Address - multipoint protocol only

RESPONSES:

[<adr>:] <nem> <value>) [,<nem> <value>]* [=<chksum>] <cr><lf>

- | | | | |
- | | | | | _ Ending
- | | | | | _ Checksum, if received
- | | | | | _ Mnemonics may be repeated
- | | | | | _ Value
- | | | | | _ Mnemonic command - see tables below
- | | | | | _ Communication Address - multipoint protocol only

COMMAND DEFINITIONS:

Set TD-2 Alarm, Data output rate or Get TD-2 data set

TD2 ?|<value> 0.0 to +3000.0 minutes per transmission
OUTPUT: [<adr>:] MTT, TCT, DIF, VAL [=<checksum>]<cr><lf>

MTT is Main Tank Temp TPK is peak of any temp
DF1 is Differential Temp 1 DF2 is Differential Temp 2
VL1 is Valley Temp 1 VL2 is Valley Temp 2
Flags are status values: Warning, Alarm

Set / Get Differential 1 Temperature Warning value.

DW1 ?|<value> -130.0 to +130.0 degrees C

Set / Get Differential 2 Temperature Warning value.

DW2 ?|<value> -130.0 to +130.0 degrees C

Set / Get Differential 1 Temperature Alarm value.

DA1 ?|<value> -130.0 to +130.0 degrees C

Set / Get Differential 2 Temperature Alarm value.

DA2 ?|<value> -130.0 to +130.0 degrees C

Set / Get High Temperature Alarm value.

HTA ?|<value> -40.0 to +180.0 degrees C

Set / Get Alarm Delay Time.

ADT ?|<value> 1.0 to +1000.0 seconds

Set / Get Hysteresis value.

HYS ?|<value> 0.1 to +100.0 degrees C

Get RTD #1 calibration offset value.

R1O ? -20.0 to +20.0 degrees C

Get RTD #2 calibration offset value.



R2O ? -20.0 to +20.0 degrees C

Get RTD #3 calibration offset value.

R3O ? -20.0 to +20.0 degrees C

NOTES:


1. All numbers are passed as ASCII strings. (CAPS LOCK ON)
2. Maximum input and output string length is 80 characters including ending.
3. All spaces and tabs outside tokens are ignored.
4. All control characters except <cr> and <lf> are ignored.



CONFIGURATION JUMPERS: (* = DEFAULT)

JP1	Difference Analog Output2	Jumper on 1&2 – Enables Voltage Jumper on 2 & 3 - Enables Current *
JP2	Difference Analog Output1	Jumper on 1 & 2 - Enables Voltage Jumper on 2 & 3 - Enables Current *
JP3	Main Tank Analog Output:	Jumper on 1 & 2 - Enables Voltage Jumper on 2 & 3 - Enables Current *
JP4	Difference Analog Output2:	Jumper on - 4 to 20 ma Jumper off - 0 to 1 ma *
JP5	Difference Analog Output1	Jumper on - 4 to 20 ma Jumper off - 0 to 1 ma *
JP6	Main Tank Analog Output:	Jumper on - 4 to 20 ma. Jumper off - 0 to 1 ma *
JMP1	RS485 Termination.	Jumper on - Enables 120 Ohm termination *

Note: remove the 120 ohm termination jumper (JMP1) for RS232 applications.




II. TD-2 INSTALLATION

This optional procedure will prevent initial false alarms while the TD-2 determines the proper alarm setpoints.

1. Follow mounting Instructions, but do not hook up the alarms or SCADA input.
2. Let the TD-2 monitor the two temperatures from a few days to a month or so to establish the alarm setpoint benchmarks. (30 days is recommended)
3. Note the valley temperature. (This is the maximum temperature differential since installation.)
4. Set the first alarm point a little beyond the maximum valley temperature.
5. Set the second alarm point 5 -10 degrees beyond the first alarm point.
6. Complete the wiring and installation to annunciation and SCADA.

Installation requires no service interruption or further calibration.



1. Mount the TD-2 on the LTC control cabinet using four machine screws.
2. Punch and mount a 3/4" conduit elbow from the underside of the TD-2 to the interior of the control cabinet. Provide AC power to the TD-2.
3. Apply a thin film of heat sink compound or silicon based grease (NO-OX works fine) to the RTD probe surfaces (located under the sensors) and attach the sensors to the tap changers and the main tank. Be sure that all sensors are located below the tank oil level near the top of the tanks and that both sensor cords are located at the bottom of the sensors. Apply RTV or Silicon around the sensors to seal out moisture.
4. Coil up the extra cable and tie wrap. If it is necessary to shorten the cable length, remove them from the NEMA box and shorten them at the terminal plug. Do not remove the cables at the magnetic end of the sensors.
5. Connect the analog points to an existing SCADA system. Program the SCADA master station for the output values selected.
6. Connect the alarm warning contact point to an existing annunciation system. The contacts are "dry" and are compatible with existing annunciators. This warning has been factory set at -1 degree C. (The warning will operate when the LTC is 1 degree hotter than the main tank.)
7. The second alarm contact is provided to provide an urgent response alarm. The contacts are "dry" and are compatible with existing annunciators. This alarm has been factory set at -5 degree C. (The alarm will operate when the LTC is 5 degree hotter than the main tank.) This alarm is to intended to indicate if an immediate response is required to prevent a failure.
8. Monitor and establish the "benchmark temperature differentials". (VALLEY TEMPERATURES)
9. Set the SCADA temperature DIFFERENTIAL alarm points slightly more negative than the lowest reading. You are looking for a condition where the LTC compartments are hotter than the main tank. This will be indicated by a negative temperature differential. Conditions where the main tank is warmer than the LTC are normal conditions.

"Valley" temperatures (**this is the one to watch as it is the maximum differential temperature since the system was last reset.**)

Ideally, the warning alarm point for the temperature differential should be set beyond the valley differential temperature. **If the alarm point is set too close, there will be nuisance alarms.** If the alarm point is set too wide, it will not alarm at all. The second alarm relay is intended to indicate a major temperature differential problem. This could be off-step, broken springs, severe arcing, etc. Emergency response is recommended for second alarm conditions.

If the SCADA system has "trending" you can get a normal temperature footprint after installation for later comparison.

Barrington consultants would appreciate any feedback about the TD-2. We want to provide top quality products to satisfied customers. We will be happy to answer any questions you might have about installation or operation of our products.

Barrington Consultants bears no responsibility for installation or user operation of the TD-2. It is up to the user to establish the proper alarm points.

TD-2 SPECIFICATIONS

RTD	-100°C to 600°C (DIN 43760 Class B) .00385 ohms/ohm/ °C
STABILITY	Maximum change in ice point resistance of less than 0.2°C/Year
REPEATABILITY	0.05% of actual span

OIL TEMP INPUT TYPE	75LB Pull Surface Magnetic mount platinum 100 Ohm RTDs (1 each for LTC compartments and main tank)
INPUT PROBE CABLE	24' type UV/SJT
INPUT SPAN	-40° C Min 200° C Max
ANALOG OUTPUT	0 - 5V, 0-1mA or 4-20mA (Independently selectable)
CALIBRATION	Automatic -40°C to 200°C
LINEARITY	Better than 0.2% of span
TEMPERATURE STABILITY	Better than .03% /°C of span
Surge Withstand	Designed to meet ANSI/IEEE C37.90
C.M.R.R.	120db DC to 60 Hz
POWER SUPPLY RANGE	115/230VAC - 50/60Hz
OPERATING TEMP.	-20°C (-40 optional heater) to +75°C
ENCLOSURE	NEMA 4 10" X 8" X 6"
<u>DIGITAL RESOLUTION:</u>	>12 bits.
<u>OVERALL ACCURACY</u>	Less than 0.3°C input temperature / display
<u>ALARM:</u>	Dry contact spst relay output rated @ 5A 250 VAC.
<u>ALARM RESPONSE TIME:</u>	Programmable - .1 sec to 1000 sec.
<u>ALARM HYSTERESIS</u>	0.1 TO 100 DEG C (DEAD BAND)
<u>DISPLAY:</u>	16 × 2 Character .39" LCD indicator for programming and display of input and output parameters and status.
<u>SUPPLY:</u>	AC: 115 or 230 VAC 50/60 Hz ± 10%,
<u>OPERATING CONDITIONS:</u>	-40°C to +75°C. 0-95% RH, non condensing.
<u>STORAGE TEMP.:</u>	-55°C to 105°C.
<u>HUMIDITY:</u>	0-95% RH, non condensing.
<u>TURN-ON TIME:</u>	Within 10 seconds to rated response.
<u>RESPONSE TIME:</u>	5 seconds to 99% of reading. (1 update/second).
<u>DAMPING FACTOR:</u>	3.0 Seconds.
<u>TD-2 LONG TERM STABILITY:</u>	Less than ±0.1% of span for six months.
<u>(D/A) LINEARITY:</u>	±0.05% of span.
<u>LINEARIZATION:</u>	better than ±0.03°C for Pt-100 RTD,
<u>CALIBRATION:</u>	adjustable on-site, factory preadjusted